

Instructions to make the CENA17H34 ADA-compliant

Follow these instructions to make sure your unit is the right height to be compliant with the standards set by the Americans with Disability Act.

Tools Needed

Philips screwdriver

Removing the Black Plates

- 1. Place the unit on its back.
- 2. Remove the 4 legs by manually unscrewing them and then set them aside.
- Unscrew the 6 screws holding the left and right plates using the Phillips screwdriver.
- 4. Pull the plates off the units.



5. To remove the kickplate, unscrew the 4 screws on each side of the kickplate. Set the screws aside

Installing the Shorter Kickplate

- 6. Using the screws you set aside in step 5, secure the shorter kickplate to the unit.
- 7. Screw the legs set aside during step 2 back onto the unit.



