



Instructions for Installing a Panel on your PNR **Model** Models: DAFF682PNR, DAFF683OSPNR

Your product is designed to accept custom overlay panels on its door.

Parts included in the PNR kit:

Screws to attach the custom panel

- (1) Replacement top hinge
- (1) Replacement bottom hinge
- (2) Plastic bushing for panel

Panel Dimensions:

Door Exterior: 23 $\frac{5}{16}$ " W x 29 $\frac{3}{4}$ " H

Overlay panel thickness: minimum $\frac{3}{4}$ " thick



Removing the Unit's Door

1. Remove the door from its chassis by unscrewing the top and bottom hinges from the cabinet and door.

Attaching the Handle and Panel

2. Attach your door handle to the panel.
3. Pull out the rubber gasket located around the inside of the door frame to access the screw holes from the inside of the door.
4. Drill holes into the door opposite the handle.
5. Place your custom panel over the door pane.
6. Using the provided screws, attach the panel by holding it in place from the front and screwing it onto the door pane from inside the door.
7. Reinstall the gasket to its original position.

Reattaching the Door

8. You will have to drill a hole into the top and bottom of the custom panel in order to connect it to the new provided hinges. To do this, line up the door in its final position and, using the hinges, mark where you will be drilling the holes.
9. Using a $\frac{3}{8}$ " drill bit, drill a hole through the top and bottom of the custom panel.
10. Insert the provided bushing into the top and bottom of the panel.